

Installation Manual

ZEKE-8-12V



Date: 02/2020

Order Code	Product Code	Description
19862	ZEKE-8-12V-BLK-WW	8W Rectangle exterior steplight, black finish. Warm white 3000K
19863	ZEKE-8-12V-BLK-W	8W Rectangle exterior steplight, black finish. White 5000K
19858	ZEKE-8-12V-SLR-WW	8W Rectangle exterior steplight, silver finish. Warm white 3000K
19859	ZEKE-8-12V-SLR-W	8W Rectangle exterior steplight, silver finish. White 5000K
19856	ZEKE-8-12V-DGR-WW	8W Rectangle exterior steplight, dark grey finish. Warm white 3000K
19857	ZEKE-8-12V-DGR-W	8W Rectangle exterior steplight, dark grey finish. White 5000K
19860	ZEKE-8-12V-WHT-WW	8W Rectangle exterior steplight, satin white finish. Warm white 3000K
19861	ZEKE-8-12V-WHT-W	8W Rectangle exterior steplight, satin white finish. White 5000K

Thank you for purchasing your new LED ZEKE-8-12V, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

Specifications

Voltage:	12V DC	Lumen (±5%):	Warm White 3000K - 500lm White 5000K - 550lm	Dimmable:	No
Power:	8W	CRI:	≥80	Operating Temp:	-30~+45
IP Rating:	65	CCT:	3000K - 5000K	Lifespan:	50,000hrs
Requires:	12V DC Constant Voltage LED Driver				



Wire in Parallel

Note: -The lamp must be installed by professional electrician
-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use
-Keep away from hot steam and corrosive gas